









S343902 Replacement Part - Royale Robooter Joystick Assembly For E80 Each




S343903 Replacement Part - Royale Robooter Joystick Knob For E40/E60-A/E60-Pro-A/E80 Each




S343905 Replacement Part - Royale Robooter Joystick Veneer Upholstery Cover RHS/LHS For E80 Each




S343870 Replacement Part - Royale Robooter Armrest w/Light Assembly For E40/E60-A/E60-Pro-A/E80 Each




S343860 Replacement Part - Royale Robooter Armrest Assembly LHS For E80 Each




S343862 Replacement Part - Royale Robooter Armrest Assembly RHS For E80 Each




S343864 Replacement Part - Royale Robooter Armrest LHS Round Cap Cover For




S343867 Replacement Part - Royale Robooter Armrest RHS Round Cap Cover For E40/E80 Each




S343875 Replacement Part - Royale Robooter Backrest Assembly (Without Backpack) For E80 Each




S343841 Replacement Accessory - Royale Robooter Backpack For E80 Each




S343884 Replacement Part - Royale Robooter Folding Lever Mechanism Assembly For E40/E60-A/E60-Pro-A/E80 Each




S343938 Replacement Part - Royale Robooter Seat Cushion For E80 Each




S343936 Replacement Part - Royale Robooter Seat Canvas Assembly For E40/E60-A/E60-Pro-A/E80 Each




S343844 Replacement Accessory - Royale Robooter Seat Belt Assembly For E40/E60-A/E60-Pro-A/E80 Each




S343845 Replacement Accessory - Royale Robooter Storage Basket For E40/E80 Each



S343889 Replacement Part - Royale Robooter Footplate Assembly For E80 Each



S343853 Replacement Part - Royale Robooter
8" PU Front Wheel Assembly For
E40/E80 Each




S343894 Replacement Part - Royale Robooter
Front Fork Assembly For E40/E80 Each




S343895 Replacement Part - Royale Robooter
Front Fork RHS/LHS Cap Cover Black
For E80 (Pair)




S343924 Replacement Part - Royale Robooter
Pneumatic Rear 10" Tyre Assembly
RHS/LHS For E80 Each




S344208 Replacement Part - Royale Robooter
Pneumatic Rear 10" Tube Only For
E80 Each




S344211 Replacement Part - Royale Robooter
Pneumatic Rear 10" Tyre Only For
E80 Each




S343933 Replacement Part - Royale Robooter
Rear Tyre Hub Cap Cover Black For
E80 (Pair)




S343912 Replacement Part - Royale Robooter
Motor Assembly LHS For E80 Each




S343915 Replacement Part - Royale Robooter
Motor Assembly RHS For E80 Each




S343851 Replacement Part - Royale Robooter
24V20AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343852 Replacement Part - Royale Robooter
24V25AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343850 Replacement Part - Royale Robooter
24V12AH Battery For E40/E60-A/E60
-Pro-A/E80 Each




S343878 Replacement Part - Royale Robooter
BatteryLocking Clip For E40/E60
-A/E60-Pro-A/E80 (Pair)




S344349 Replacement Charger - Royale
Robooter Universal 3AH Charger
For E40/E80 Each




S343879 Replacement Part - Royale Robooter
Charging Cable For AU Wall Socket
For E40/E60-A/E60-Pro-A/E80 Each




S343928 Replacement Part - Royale Robooter
Rear Black Shroud Assembly For
E40/E80 Each




S343932 Replacement Part - Royale Robooter
Rear Manual Drive Locking Lever Red
For E40/E60-A/E60-Pro-A/E80 Each




S343849 Replacement Part - Royale Robooter
2" Anti-Tip Wheel w/Screws For E80
Each




S343858 Replacement Part - Royale Robooter
Anti-Tip Bar (Without Wheel) For E80
Each




S343885 Replacement Part - Royale Robooter
Folding Roller Wheel LHS For
E40/E60-A/E60-Pro-A/E80 Each




S343886 Replacement Part - Royale Robooter
Folding Roller Wheel RHS For
E40/E60-A/E60-Pro-A/E80 Each




S343881 Replacement Part - Royale Robooter
Control Box For E80 Each




S343883 Replacement Part - Royale Robooter
Control Box Mounting Plate For
E80 Each



S343906 Replacement Part - Royale Robooter
M3x8 Screws For E40/E60-A/E60
-Pro-A/E80 (Pack of 6)



S343907 Replacement Part - Royale Robooter
M4x12 Screws For E40/E60
-A/E60-Pro-A/E80 Each(Pack of 8)



S343908 Replacement Part - Royale Robooter
M4x16 Screws For E40/E60
-A/E60-Pro-A/E80 (Pack of 6)

S343877 Replacement Part - Royale Robooter Battery Connection Cable For E40/E60-A/E60-Pro-A/E80 Each

S343876 Replacement Part - Royale Robooter Backrest Folding Component For E40/E80 Each

S343941 Replacement Part - Royale Robooter Upper and Lower Control Connection Cable RHS/LHS Dual Control Assembly For E40/E60-A/E60-Pro-A/E80 Each
